


# FURNACE CONTROL BOARD 2



Area # 7b

Area # 7c

Area # 7a

Line Voltage Neutrals

Area # 8

Area # 6

Area # 9

Area # 5

Area # 4

Area # 3

Area # 2

Area # 1

Fault LED. Codes are displayed on blower section.

# FURNACE CONTROL BOARD \_ Directions

▶ (AREA #1)

**DIP SWITCHES #1 and #2** -----

Set Timing for Blower "Heat Off" delay:

Both #1 & #2 **ON** = 90 second delay  
 #1 **OFF** & #2 **ON** = 120 sec delay  
 #1 **ON** & #2 **OFF** = 150 sec delay  
 Both #1 & #2 **OFF** = 180 sec delay

**DIP SWITCH #3** -----

**ON** = 10 Minute Delay before High Fire  
**OFF** = 5 Minute Delay before High Fire

▶ (AREA #2)

**JUMPER SETTING** -----

Set jumper to brackets indicated for use with T-Stat for Single Stage Heat or for use with T-Stat that has Two Stage Heat.

▶ (AREA #3)

**Green CFM LED Indicator** -----

Blinks once for every 100 CFM

▶ (AREA #4)

**DIP SWITCHES #5 and #6**

**BLOWER PROFILE FOR COOLING**

- BOTH #5 & #6 OFF** ---- Runs at 100% for 1 minute after Outdoor unit cycles off.
- #5 OFF / #6 ON** ----- Runs at 50% speed for first 30 seconds on a call for cooling then finishes the Cooling Cycle at 100% speed, then continues at the 100% speed for 1 minute after the outdoor unit cycles off.
- #5 ON / #6 OFF** ----- Runs at 82% for the first 7.5 minutes on a call for Cooling then finish cycle at 100%, and continues at 100% for 1 minute after the outdoor unit cycles off.
- BOTH #5 & #6 ON** ----- Runs at 50% speed for ½ minute then speeds to 82% for 7 ½ minutes, then finishes the Cooling Cycle at 100% and continues at 50% for ½ minute after the outdoor unit cycles off.

**DIP SWITCHES #7 and #8**

		FURNACES BTUH X 1000 (Temp Rise)			
		45	70	90	115
#7 OFF	#8 OFF	51°	50°	50°	57°
#7 ON	#8 OFF	47°	46°	47°	56°
#7 OFF	#8 ON	43°	42°	44°	54°
#7 ON	#8 ON	40°	39°	42°	53°

Above allows roughly a 10° adjustment to each model furnace. Adjust in accordance with specific name plate requirements.

▶ **(AREA #5)** DIP SWITCHES #1 and #2 →

		FURNACES BTUH X 1000 (Blower CFM)			
		45	70	90	115
#1 OFF	#2 OFF	1.5 Ton	1.5 Ton	2 Ton	2 Ton
#1 ON	#2 OFF	2 Ton	2 Ton	2.5 Ton (-)	2.5 Ton (-)
#1 ON	#2 OFF	—	—	3 Ton (+)	3 Ton (+)
#1 OFF	#2 ON	2.5 Ton	2.5 Ton (-)	3.5 Ton	3.5 Ton
#1 OFF	#2 ON	—	3 Ton (+)	—	—
#1 ON	#2 ON	3 Ton	3.5 Ton	4 Ton (-)	4 Ton (-)
#1 ON	#2 ON	—	4 Ton (+)	5 Ton (+)	5 Ton (+)

DIP SWITCHES #3 and #4

See above (+) and (-) Indicators :

(+) = #3 ON / #4 OFF = 10% CFM Increase

(-) = #3 OFF / #4 ON = 10% CFM Decrease

**#3 & #4 >>>> NEVER BOTH "ON" AT SAME TIME !!!**

- ▶ **(AREA #7a)** DEHUM Terminal: When energized allows the blower to operate at full operational speed. When de-energized it lets blower operate at 80% of full operational speed.
- ▶ **(AREA #7b)** Energizes on a call for De-humidification and indicates that the blower is operating at a reduced CFM.)
- ▶ **(AREA #7c)** W14 Jumper must be cut to allow the above dehumidification function.
- ▶ **(AREA #9)** HUM Terminal: (provides 120 volts for Adding a Humidifier.)
- ▶ **(AREA #10)** EAC Terminal: (provides 120 volts for adding an Electronic Air Cleaner.)  
**(Fault Code Light)** Red Fault Code Light: (Fault Codes are displayed on the door of the blower section.)

**NOTES:**

- Set cooling airflow first then set heating air flow.
- On a call for blower only (constant fan), blower operates at 56% of full CFM setting.
- Dip Switch positions are only established when the furnace is powered up. Power must be OFF when positioning switches.