

**MBE & AEPF
Two Stage Operation Wiring
Diagram**

OUTDOOR UNIT

CONTACTOR (1ST STAGE WIRE)


AUX. HEAT

REVERSING VALVE

24 VOLT COMMON

SOLENOID (2ND STAGE)

24 VOLT HOT



CONTACTOR (1ST STAGE)

SOLENOID (2ND STAGE)
Also High speed Fan

IMPORTANT!
Remove the orange "On Board" jumper from the "O" terminal and discard.

IMPORTANT!
Turn #4 Dip Switch OFF for Two Stage Operation

To Indoor Electric Heater