

# DIP SWITCH SETTINGS

## MBE / CFM Chart



✓ = switch "ON"  
Blank = switch "OFF"

|                |                 | DIP SWITCH SETTINGS |   |   |    |   |   |   |   |
|----------------|-----------------|---------------------|---|---|----|---|---|---|---|
|                |                 | 1                   | 2 | 3 | 4* | 5 | 6 | 7 | 8 |
| <b>MBE1200</b> | <b>Ton / KW</b> |                     |   |   |    |   |   |   |   |
|                | 1.5 / 5         | ✓                   | ✓ |   | ✓  | ✓ | ✓ |   |   |
|                | 1.5 / 8         | ✓                   | ✓ |   | ✓  | ✓ | ✓ |   |   |
|                | 2.0 / 8         |                     | ✓ |   | ✓  |   | ✓ |   |   |
|                | 2.0 / 10        |                     | ✓ |   | ✓  |   | ✓ |   |   |
|                | 2.5 / 10        | ✓                   |   |   | ✓  | ✓ |   |   |   |
|                | 3.0 / 10        |                     |   |   | ✓  |   |   |   |   |
|                | 3.0 / 15        |                     |   |   | ✓  |   |   |   |   |
| <b>MBE1600</b> | <b>Ton / KW</b> |                     |   |   |    |   |   |   |   |
|                | 2.5 / 10        | ✓                   | ✓ |   | ✓  | ✓ | ✓ |   |   |
|                | 3.0 / 10        |                     | ✓ |   | ✓  |   | ✓ |   |   |
|                | 3.0 / 15        |                     | ✓ |   | ✓  |   | ✓ |   |   |
|                | 3.5 / 10        | ✓                   |   |   | ✓  | ✓ |   |   |   |
|                | 3.5 / 15        | ✓                   |   |   | ✓  | ✓ |   |   |   |
|                | 4.0 / 15        |                     |   |   | ✓  |   |   |   |   |
| <b>MBE2000</b> | <b>Ton / KW</b> |                     |   |   |    |   |   |   |   |
|                | 3.0 / 10        | ✓                   | ✓ |   | ✓  | ✓ | ✓ |   |   |
|                | 3.0 / 15        | ✓                   | ✓ |   | ✓  | ✓ | ✓ |   |   |
|                | 3.5 / 10        |                     | ✓ |   | ✓  |   | ✓ |   |   |
|                | 3.5 / 15        |                     | ✓ |   | ✓  |   | ✓ |   |   |
|                | 4.0 / 15        | ✓                   |   |   | ✓  | ✓ |   |   |   |
|                | 4.0 / 20        | ✓                   |   |   | ✓  | ✓ |   |   |   |
|                | 5.0 / 15        |                     |   |   | ✓  |   |   |   |   |
|                | 5.0 / 20        | ✓                   |   |   | ✓  |   |   |   |   |

\* Turn #4 "OFF" for use with ASZ16 / ASZ18 / ASX16 / ASX18

Cooling & Heat Pump settings are nominal 400 cfm per ton.